




VAC, Valve Accessories & Controls.
www.vac.se

V200 POSITIONER

Installation, Operation and Maintenance Instruction





V200 POSITIONER

www.vacaccessories.com

CONTENTS

1 INTRODUCTION	4
1.1 Principle of Operation.....	4
1.2 Product Identification.....	4
1.3 Air quality recommendations.....	5
1.4 Safety Instructions.....	5
2 INSTALLATION.....	6
2.1 Connections	6
2.2 General mounting instructions	7
2.2.1 Rotary actuators.....	7
2.2.2 Linear actuators	7
2.3 Installation instructions for rotary actuators.....	8
2.3.1 Double acting	8
2.3.2 Single acting.....	8
2.4 Installation instructions for linear actuators	9
2.4.1 Double acting	9
2.4.2 Single acting.....	9
2.5 Cam.....	10
2.5.1 Adjustments	10
2.5.2 Cam specifications.....	10
2.6 Spindle(Drive)	11
2.6.1 Spindle removal	11
2.6.2 Spindle mounting	11
2.7 Installing IP converter.....	12
2.7.1 Internal IP converter.....	12
2.8 4-20 mA connection	13
2.8.1 Connecting the control signal.....	13
2.8.2 Checking the control signal	13
2.8.3 Bench test with calibrator	13
2.8.4 Checking the IP internal circuit.....	13
2.9 Calibration.....	14
2.10 Front cover and Indicator	15
2.10.1 Removing the front cover	15
2.10.2 Removing flat indicator cover	15
2.10.3 Removing Dome indicator cover.....	15
2.10.4 Changing the sealings in the front cover.....	15
2.10.5 Installing flat indicator cover.....	16
2.10.6 Installing Dome indicator cover	16
2.10.7 Removing the indicator	16
2.11 Main supply filter for IP converter.....	17
2.12 Pilot valve remove and install.....	18
---- Intentionally blank	19
3 SPARE PARTS	20
3.1 Exploded drawing.....	20
3.2 Spare parts list	21
4 SPECIFICATIONS.....	22
4.1 Specifications V200.....	22
5 DIMENSION	23
5.1 V200 P/E std	23

1 INTRODUCTION

1.1 Principle of Operation

The V200 incorporates the force balance principal of operation. The desired value, in the form of pressure, affects the membrane(1) with the force that is created and transferred to the balance arm(2). The opposing force, which represents the actual control value, is provided by the feedback spring(5) and creating force in the opposite direction on the balance arm(2). The feedback spring, resting on the feedback arm(3), is positioned by the shape and response of the cam. The cam(4) is connected to the cylinder's (actuator) piston rod via the drive.



The pilot valve(6) is connected to the balance

arm and follows the balance arm's movement.

The system is stable when the gold plated spool(7) is in the neutral position and the forces that affect the balance arm is in equilibrium.

As soon as a signal change occurs or a change in the position of the valve/actuator package occurs, the "force balance" is also changed and the spool responds. Air immediately begins to flow into the part of the actuator (C+ or C-) which allows the feedback mechanism to return the spool to the neutral position.


The system is self-stabilizing and searches for a steady state position.



1.2 Product identification

The V200 identification tags, Serial number tag(1), product model tag(2) and feedback option tags(3), are placed as shown.

The product model tag contains information on control signal, maximum working pressure and temperature ranges. Other information can be shown depending on the model.





V200 POSITIONER

www.vacaccessories.com

1.3 Air quality recommendations

Poor air quality is one of the main causes of premature functional problems with pneumatic and electro pneumatic equipment. The pilot valve and IP-converter are precision instruments, and are therefore the most sensitive parts of the positioner.

a) Water in the supply air is a natural occurrence. This happens when air is compressed. The compression heats the air and the natural degree of water in the air can remain as moisture. When the air cools in pipes etc. the moisture condenses and becomes liquid water. Large quantities can build and sometimes flood small water separators. This excess water will eventually reach the control valve and positioner. This can cause corrosion damage to the IP converter, causing the unit to malfunction.

We strongly recommend the use of water separators with adequate capacity. Coalescing filters from a reputable manufacturer is an inexpensive way to help prevent unit malfunctions or failures, and add life to the product. These filters remove particles and moisture from air lines.

b) Oil in the supply air usually is from the main compressor. Oil can clog the small nozzles and disturb the flapper in the IP-converter. It can also cause the gold plated spool to “drag” within the pilot valve. The result is poor control or in the worst case, failure.

c) Particles in the air usually occur because of corrosion. Dirt and particles can block the small nozzles of the IP-converter. They can also cause the pilot valve to malfunction. The unit may completely fail.

To ensure normal operational safety with VAC positioner products, we recommend that a water separator and a <80 micrometer filter are mounted as close to the product as possible. If large amounts of oil are present an oil separator should be installed as well.

To further increase operational safety, we recommend that the working air is clean, dry and free of moisture, water, oil, particles and other contaminants, in accordance with the standard ANSI/ISA- 7.0.01- 1996

1.4 Safety Instructions



CAUTION: Beware of moving parts when positioner is operated!



CAUTION: Beware of parts with live voltage!

A voltage, which is normally not dangerous, is supplied to the positioner.

Avoid touching live parts and bare wires as well as short circuiting live parts and the housing.



CAUTION: Do not dismantle a pressurized positioner!

Dismantling a pressurized positioner will result in uncontrolled pressure release. Always isolate the relevant part of the pipeline. Release the pressure from the positioner and the piping. Failure to do this may result in damage or personal injury.



CAUTION: Do not exceed the positioner performance limitations!

Exceeding the limitations marked on the positioner may cause damage to the positioner, actuator and valve. Damage or personal injury may result.

2. INSTALLATION

2.1 Connections

S – Supply air

V200P: max. 145 PSI / 1 MPa

V200E: 23 - 145 PSI / 0,15 -1 MPa

I – Input, pressure signal

V200P: 3-15 PSI / 20-100 kPa

V200E: Plugged

I_E – Input, current signal




V200E: 4-20 mA (Ri max 250 ohm)

V200P: Plugged

C+ - Actuator connection + stroke

C- - Actuator connection - stroke

OUT - All air from the actuator, IP and positioner is vented through this port.
Standard equipped with a bug screen/silencer



Air connections for male 1/4" NPT or G 1/4".

Gauge connections for male 1/8" NPT or G1/8".

Cable entry for male 1/2" NPT or M20 cable fittings.

G threads are indicated by an engraved G on the air connection side of the positioner.

Gauge ports I, C+, C- and S are factory plugged. Remove plugs and replace with gauges.



The IP connection must be plugged in V200E.
The I_E entries should be plugged in V200P




V200 POSITIONER

www.vacaccessories.com

2.2 General mounting instructions.


The V200 has the ISO F05 hole pattern(1) and 2¼" x 2¼" hole pattern(2).



2.2.1 Rotary actuator


The VAC V200 has a very stable and properly sized drive shaft bearing. However, the positioner drive(A) should be aligned properly to the rotary actuator spindle(B).

A relatively small error combined with a rigid coupling can create very powerful radial forces, which can overload and cause premature wear.





2.2.2 Linear actuator

When mounting to linear actuators, the positioner should be attached in such a way that its drive is in the center (mid stroke) of the actuator's stroke. Proper installation and alignment will minimize linearity error.







2.3 Installation instructions for rotary actuators

2.3.1 Double acting




2.3.2 Single acting




2.4 Installation instructions for linear actuators

2.4.1 Double acting



2.4.2 Single acting



2.5 Cam




The V200 is standard shipped with the C1-cam, factory set for $90^\circ \pm 1^\circ$, direct (CCW) turning.


2.5.1 Adjustments

Remove the front cover and indicator.
(see page 15)

1. Loosen the locking screw(2) and the cam nut(1).
2. Stroke the valve/actuator to the stop/end position at 0% input.
3. Turn the cam(3) so that the index mark(5) for the selected curve aligns with the ball bearing(4). A small gap between the roller and the cam tip is desirable.
4. Tighten the cam nut by hand(1).
Check that the locking screw(2) is still loose.
(if not, loosen the locking screw slightly and tighten the nut again).
5. Tighten the locking screw(2).
Do not tighten cam nut with screw(2) down.



Cam setting.eps



Cam Nut.eps

2.5.2 Cam specifications C1

Index mark / Starting point of rotation *


- | | |
|-----|------------------------------------|
| 5. | 90° Linear 0-100% CCW |
| 6. | 180° Linear 0-100% CW |
| 6. | 90° Linear 0-50% CW split range |
| 7. | 90° Linear 50-100% CW split range |
| 8. | 90° Linear 0-100% CW |
| 9. | 180° Linear 0-100% CCW |
| 10. | 90° Linear 0-50% CCW split range |
| 11. | 90° Linear 50-100% CCW split range |

*Increasing signal rotation.


Most valves rotate CW to close / CCW to open



When field reversing action of positioner tubing must be reversed as well
(see page 7 and 8)



Most common for fail open valves



Cam Marking.eps




V200 POSITIONER

www.vacaccessories.com


2.6 Spindle (Drive)

VAC offers a variety of spindles/drives(1), suitable for the most frequently used actuator types.



2.6.1 Spindle Removal

Release the spindle/drive by prying with two screwdrivers, equally under the edges(2) of the spindle/drive, using the housing as fulcrum. The spindle has a snap ring that is “released” with the equal pressure.




2.6.2 Spindle Mounting

Press the spindle down into the spindle shaft hole.

Turn the flats(3) into place and press down.

Check to see that the spindle/drive is set securely in place.

To install the spindle correctly will result in two “snaps” of the spindle into the housing.






2.7 Installing IP converter

2.7.1 Internal IP Converter

Remove the front cover and indicator.
(see page 15)

1. Loosen the two screws that secure the pneumatic sealing plate(1) and remove the plate.
2. Make sure the two O-rings(2) are still in the positioner housing.
3. Install the IP converter(3) and tighten the screws(4).
4. Install the 1/4" plug(5) in the port marked I.





V200 POSITIONER

www.vacaccessories.com


2.8 4-20 mA connection

2.8.1 Connecting the control signal

Remove the front cover and indicator.
(see page 15)

Terminal block(1) is now easily accessible. Connect the cables to their respective pole.

Maximum cable size AWG 13 (2,5 mm²)



2.8.2 Checking the control signal

The control signal can be checked without having to break the signal loop. This is done by connecting a low ohmic ampere meter over the test points(2).



2.8.3 Bench test with the calibrator

When bench testing, it is possible to connect the control signal (signal generator clips) to the two points(3), thus eliminating the need for temporary leads.

2.8.4 Checking the IP internal circuit

With an ohm meter connected over the two test points(3) it is possible to check the IP's internal circuit.

At room temperature the meter should read ~150 - 200 Ohms. No reading indicates an internal circuit break and the IP converter needs replacement.



The IP converter is factory-adjusted. No extra range or zero adjustments are necessary.

2.9 Calibration



The V200 is delivered factory calibrated 0-100 % $\pm 1\%$.

Calibration procedure



Zero position

Note: Always set zero first!

1. Set 0% input signal.
2. Wait until the valve/actuator has responded.
3. Adjust the zero position by turning the zero screw(1), with a screwdriver.

Range (Span)

4. Increase to 100% input signal.
5. Wait until the valve/actuator has responded.
6. Adjust the range (span) by turning the range wheel(2).



Check the zero position


Make fine adjustments if necessary.*

*When split ranging, where zero can be a signal other than 0%, the steps 1-6 must be repeated until the desired setting has been reached.

2.10 Front cover and indicator


2.10.1 Removing the front cover

Loosen the two screws(1) and remove the front cover.




2.10.2 Removing flat indicator cover

With the main cover removed, the indicator cover(2) (clear cover) can be removed with pressure from the backside.



2.10.3 Removing Dome indicator cover


Due to the combined depth of the dome indicator and V200 cover, care should be exercised when removing the dome. It is recommended that something sturdy and protective be placed under the dome and equal pressure applied to the cover. The dome should release without damage.



2.10.4 Changing the sealing in the front cover


Remove the O-ring(4) and replace if needed.

Check the O-ring(5) on the backside of the front cover and replace if needed.



2.10.5 Installing flat indicator cover


Place the indicator cover(1) facing down toward the front cover. Press in the center of the indicator cover until it snaps into place.



2.10.6 Installing Dome Indicator cover

Place the dome indicator cover(2) so that it is aligned with its seat in the front cover on one side. Use inside of palm and give the indicator cover a hard distinctive punch.

Adjust the display position by turning the indicator cover(2) to its desired position-it is a reasonably tight friction fit.



2.10.7 Removing the indicator

Pull the indicator(6) straight up; it is a friction fit.

Important Note!


Note the indicator's position so it can be installed in the same position.

Installing the indicator

Install the indicator in place over the drive shaft and press it straight down.

Be sure to press the indicator completely down so that it does not interfere with the indicator cover (clear cover).

Turn the indicator to the proper display





2.11 Main supply filter for IP converter

Changing the filter

1. Turn off or disconnect the main air supply.

Should air supply not be disconnected or turned off, the pressure may cause the filter cover to eject from the unit.

2. Loosen the screw(1) and remove filter cover(2)
3. Cautiously remove the filter(3) with a sharp pointed object e.g. a pocket knife.
4. Press the new filter(3) into the housing.
5. Check the O-ring(4) and replace if needed.
5. Install the filter cover(2) and tighten the screw(1)



If the filter(3) shows traces of oil or water, check the water/oil separator in the supply line.

Oil and water can cause functional problems in the IP converter.

2.12 Pilot valve

Removal

Remove the front cover and indicator. (see p.15)

Loosen the pilot retaining screw(1).
Lift the pilot valve(2) straight up.

Cleaning

Remove the gold plated spool(3) from the valve housing

Clean the parts with a soft cloth and pipe cleaner using alcohol, acetone or something similar.

Blow dry with clean, pressurized air.
Install the spool back in the valve housing.


Place the gold plated spool in its "working position".
(all four pistons inside the valve housing)
Slowly lift the pilot valve in one end.
The spool should start to glide before the angle exceeds 20°. (see sketch)

If any of the parts show signs of wear, we recommend replacing with a new pilot valve assembly.

The pilot valve's parts are matched to attain the best possible performance. Mixing of parts can result in high excessive bleed and/or poor function.

Install Pilot

Check the pilot valve's five O-rings(4).
Be sure that the gold plated spool's "gap"(5) fits over the balance arm(6) and place the valve straight down into place. Tighten the screw(1).






V200 POSITIONER

www.vacaccessories.com

Intentionally blank

3. SPARE PARTS

3.1 Exploded drawing





V200 POSITIONER

www.vacaccessories.com

3.2 Spare parts list

Item	Description	Material	Part no	Qty	Item	Description	Material	Part no	Qty
1	Housing	Aluminum, painted	n/a	1	24	Screw ISO 7048 M5x14	Stainless Steel	7048051414	1
	- Bearing 15x8		171508	2	25	O-ring Ø3x2 NBR70	Nitrile Rubber	OR3x2NBR	2
	- Relief Valve Washer	Stainless Steel	90126	2	26	O-ring Ø5x2 NBR70	Nitrile Rubber	OR5x2NBR	1
	- Rubber Washer	Nitrile Rubber	90035NBR	2	28	Screw ISO 7048 M5x14	Stainless Steel	7048051414	4
	- Rubber Hose	Nitrile Rubber	n/a	1	30	Filter Cover	Stainless Steel	90032	1
2	Feedback Arm Assembled		91002	1		- Screw ISO 7048 M4x8/4	Stainless Steel	7048040804	1
	- Feedback Arm	Aluminum, painted	90006	1	31	O-ring Ø3,1x1,6 NBR70	Nitrile Rubber	OR3,1x1,6NBR1	1
	- Ball Bearing	Stainless Steel	100404	1	32	Main Filter	Plastic <PP>	90033	1
	- Screw ISO 7500C M4x12	Stainless Steel	7500C041212	1	33	O-ring Ø17,5x1,5 NBR70	Nitrile Rubber	OR17,5x1,5NBR1	1
	- Bearing 8x8		100808	2	37	Drive Shaft	Stainless Steel	90029	1
3	Feedback Spring Assembled		91018	1		- O-ring Ø12x2 NBR70	Nitrile Rubber	OR12x2NBR	1
	- Spring Nut mk III	Zink	90149	1		- O-ring Ø15x2 NBR70	Nitrile Rubber	OR15x2NBR	1
	- Range Screw mk III	Zink	90146	1	38	Spindle*	Stainless Steel	90092	1
	- Range Nut L	Zink	90147	1		- Circlip spindle	Stainless Steel	90093	1
	- Range Nut R	Zink	90148	1	41	Plug 1/4"	Brass, Nickel plated	261014	1
	- Top Disc	Zink	90150	1	42	Bug Screen / Silencer	Plated Brass	400148	1
	- Knurled Knob M4 flat	Plastic <PA>	037040259905	1	43	Plug 1/8"	Plastic <PA>	90103	4
	- Feedback Spring	Stainless Steel	90018	1	45	Plug Conduit Holes	Plastic <PE HD>	90136	4
	- Screw ISO 4017 M4x60/60z	Stainless steel	4017046060z	1	48	Screw ISO 7048 M4x8/8	Stainless Steel	7048040808	1
	- Washer DIN 137B44	Steel, Zinkplated	137B44	1	49	Washer ISO 7089-4	Stainless Steel	70894	1
	- Washer ISO 7089-4	Stainless Steel	708904	1	50	Zero Plug	Nitrile Rubber	90037	1
	- Nut ISO 4032 M6M M4	Stainless Steel	93404	1	52	Dome Indicator B/Y Kit		93008	1
	- Washer ISO 7093-4	Stainless Steel	709304	1		- Dome Indicator B/Y	Plastic <PC/ABS>	92062	1
	- Spring Clip mk III	Steel	90151	1		- Circlip Indicator Flat	Stainless Steel	90137	1
4	Membrane Plate with tube	Aluminum	92177	1		- Dome Indicator Cover	Plastic <PC>	90044	1
	- Brass tube	Brass	n/a	1	53	IP converter		91006	1
	- O-ring Ø3x2 NBR70	Nitrile Rubber	OR3x2NBR	3		- Screw ISO 7045 M4x35/10	Stainless Steel	7045043510	2
	- O-ring Ø38x2 NBR70	Nitrile Rubber	OR38x2NBR	1		- Pin FRP 6x22 Ni	Steel, Nickel plated	87520622	2
	- O-ring Ø7x2 NBR70	Nitrile Rubber	OR7x2NBR	1		- Washer ISO 7089-4	Stainless Steel	70894	2
5	Membrane disc	Aluminum	90133	1	54	V200 E to P Conversion Plate		91000	1
6	Membrane	Nitrile Rubber	90180NP	1		- Sealing plate mkII	Zink	90156	1
7	Membrane Washer	Stainless Steel	90009	1		- Screw ISO 7045 M4x35/10	Stainless Steel	7045043510	2
8	Screw ISO 7047 M4x12/12	Stainless Steel	7047041212	1	55	Stability Kit**		93027	1
9	Balance Arm	Stainless Steel	91003	1		- Stability Plate Upper	Aluminum, Anodized	90039	1
10	Screw ISO 7047 M4x08/08	Stainless Steel	7047040808	2		- Stability Plate Lower	Aluminum, Anodized	90040	1
11	Guide Pin	Stainless Steel	90024	1		- Screw ISO 7048 M5x14/14	Stainless Steel	7048051414	1
12	Screw ISO 7048 M4x16/16	Stainless Steel	7048041616	2		- Rubber Plug	Nitrile Rubber	90036	1
13	Cam*	Stainless Steel	92031	1	56***	Gauge 0-30psi Bottom mount	Aluminum	400502	1
14	Cam Nut	Zink	90096	1	57***	Gauge 0-30psi Back mount	Aluminum	400500	1
	- Screw ISO 7048 M4x8/8	Stainless Steel	7048040808	1	58***	Gauge 0-160psi Back mount	Aluminum	400501	3
15	Indicator Screw	Zink	90096	1					
17	Indicator Arrow	Plastic <PC/ABS>	90049A	1					
	- Indicator Flag	Plastic <PC/ABS>	90049F	1					
	- Circlip Indicator Flat	Stainless Steel	90137	1					
18	Front Cover Assembled		91001	1					
	- Front Cover	Aluminum, painted	90004	1					
	- Screw ISO 4017 M6x40/10z	Stainless Steel	4017064010z	2					
	- Washer ISO 7089-6	Stainless Steel	708906	2					
	- O-ring Ø5,1x1,6 NBR70	Nitrile Rubber	OR5,1x1,6NBR	2					
	- Front label 0-90-0 (std)*	Plastic <PC>	92018	1					
19	O-ring Ø70x1,5 NBR70	Nitrile Rubber	OR70x1,5NBR	1					
20	Indicator cover	Plastic <PC>	90038	1					
21	O-ring Ø160x2 NBR70	Nitrile Rubber	OR160x2NBR	1					
22	Pilot Valve SG (1)		91010	1					
	- Pilot Valve HG (2)		91008	1					
	- Pilot Valve SHG (3)		91009	1					
	- Pilot Valve SHGHF (4)		91019	1					
	- Pilot Valve LB		91020	1					
	- Valve Block	Aluminium	n/a	1					
	- Valve Bushing	Stainless Steel	n/a	3					
	- Spool	Stainless Steel, Gold plated n/a		1					
	- O-ring Ø7,65x1,63 NBR70	Nitrile rubber	OR7,65x1,63NBR	5					
	- Screw ISO 4017 M5x30/10	Stainless Steel	4017053010	1					
23	Cover plate	Aluminum, painted	90080	1					

*Cam with other ranges, front labels with other scale readings and spindles suitable for the most frequently used actuator types, are available.

** Certain valve/actuator packages may need additional field stability, which can be accomplished with the stability kit (100% to 300% depending on orientation of the kit).

***Gauges available as an option. Also available in stainless steel.

..... 0-30 psi for I port

..... 0-160 psi for C+, C- and S port



V200 POSITIONER

www.vac.se

4. SPECIFICATIONS

4.1 Specifications V200

	Pneumatic V200P	Electropneumatic V200E	Electropneumatic Intrinsically Safe V200IS
Input Signal:	3-15 PSI	4-20mA (Max:Ri 250 Ohm)	4-20mA (Max:Ri 250 Ohm)
Supply Pressure:	<145 PSI (<1MPa)	21.8-145 PSI (0.15-1MPa)	21.8-145 PSI (0.15-1MPa)
Linearity error:	<0.7% f.s	<1.0% f.s	<1.0% f.s
Hysteresis:	<0.4% f.s	<0.6% f.s	<0.6% f.s
Repeatability:	<0.3% f.s	<0.5% f.s	<0.5% f.s
Temperature range:	-40° to +185 F -40° to +85°C	-40° to +185 F -40° to +85°C	-40° to +185 F * -40° to +85°C* *Temp.range depending on certification
Values with standard pilot valve, LB installed.			
Pressure gain:			
@87 PSI (600kPa)	240:1	240:1	240:1
Bleed Rate:	SCFM (SLPM)	SCFM (SLPM)	SCFM (SLPM)
@87PSI (600kPa)	0.2 (5.6)	0.25 (7.0)	0.25 (7.0)
Air Delivery	SCFM (SLPM)	SCFM (SLPM)	SCFM (SLPM)
@87 PSI (600kPa)	28.3 (800)	28.3 (800)	28.3 (800)
Air connections:	1/4" NPT (optional G threads)	1/4" NPT (optional G threads)	1/4" NPT (optional G threads)
Gauges:	1/8" NPT (optional G threads)	1/8" NPT (optional G threads)	1/8" NPT (optional G threads)
Cable entry:	1/2" NPT (optional M20x1.5)	1/2" NPT (optional M20x1.5)	1/2" NPT (optional M20x1.5)
Ingress & corrosion protection:	NEMA 4X and IP66	NEMA 4X and IP66	NEMA 4X and IP66
Standard coating:	Polyester	Polyester	Polyester
Weight:	3.2 lbs (1,45kg)	3.8 lbs (1.7kg)	3.8 lbs (1.7kg)
Weight with gauges:	3.4 lbs (1,54kg)	4.2 lbs (1.9kg)	4.2 lbs (1.9kg)

Valve types. (SG/LB valve is installed as standard)

			<u>SG/LB</u>	<u>SHG (3)</u>	<u>SHGSHF (4)</u>
Pressure Gain:	@ 29 PSI (0.2MPa)	Poutput / Pinput	80	367	370
	@ 87 PSI (0.6MPa)	Poutput / Pinput	240	1100	1100
	@ 145 PSI (1.0MPa)	Poutput / Pinput	400	1833	1830
Pressure Gain:	Any	%Poutput / %Pinput	16	79	72
Acc. to ISA S75.13					
Air Delivery:	@ 29 PSI (0.2MPa)	SCFM/(SLPM)	9.4 / (270)	10.5 / (297)	16.6 / (470)
	@ 87 PSI (0.6MPa)	SCFM/(SLPM)	28.3 / (800)	31.5 / (890)	50.0 / (1400)
	@ 145 PSI (1.0MPa)	SCFM/(SLPM)	47.1 / (1330)	52.5 / (1486)	83.4 / (2330)
Bleed Rate:	@ 29 PSI (0.2MPa)	SCFM/(SLPM)	0.07 / (3.4)	0.28 / (7.9)	0.4 / (12.3)
	@ 87 PSI (0.6MPa)	SCFM/(SLPM)	0.2 / (5.6)	0.83 / (23.5)	1.3 / (36.8)
	@ 145 PSI (1.0MPa)	SCFM/(SLPM)	0.35 / (10.0)	1.38 / (39.1)	2.2 / (61.3)

Options: Feedback Spring for 6-30 PSI (40-200kPa) input signal. Gauges. Stability kit, feedback modules.





VALVE ACCESSORIES & CONTROLS

200 Jade Park
Chelsea, AL 35043
TEL: (1) 205-678 0507
FAX: (1) 205-678-0510
info@vacaccessories.com
www.vacaccessories.com

VALVE ACCESSORIES & CONTROLS

292 Hendricks Road
Bolton Landing, NY 12814
TEL: (1) 518-222-1170
FAX: (1) 518-514-1262
bobg@vacaccessories.com

VALVE ACCESSORIES & CONTROLS

12942 Bedford Falls Drive
Cypress, TX 77429
TEL: (1) 713-493-2624
Cell: (1) 713-253-7781
FAX: (1) 281-256-9399
randye@vacaccessories.com



Designed and manufactured in Sweden by:
VAC, VALVE ACCESSORIES & CONTROLS SWEDEN AB
Box 580, SE-175 26 JÄRFÄLLA • Veddestavägen 13, SE-175 62 JÄRFÄLLA
Tel: +46 (0)8 568 200 50 • Fax: +46 (0)8 580 361 35
info@vac.se • www.vac.se